






MANUAL



PA2240BP



Removable rack ears





Front panel

1. Power switch

To turn the power on and off.

2. Overload indicator CH1 & CH2

This red LED illuminates when one of the protections have been activated. No sound will be heard anymore. This will be in case of overheating being the result of drawing too much power from your amplifier or the impedance connected is below the minimum load impedance.

See also point 17 "bass control".

3. Level indicators/clip-limit CH1 & CH2

The bottom LED will light green after powering on. To work under normal conditions the volume indicator should be kept under 0dB. At +4dB a limiter will be activated. This red LED indicates that the "auto gain circuit" reduces the level below clipping. This can be bypassed by qualified personnel only (see jumper inside), but voids the guarantee and the LED will continue to flicker.

This is NOT a clip indicator!

When the overheating protection circuit is active, the level indicators will all go dark. If this occurs regularly, check the total load impedance and make sure the airflow around the amplifier is not obstructed.

4. Prior LED CH1 & CH2

This yellow LED will illuminate when the prior input has been selected by means of the priority input contact (see 11b). In bridge mode only the indication of CH1 are valid.


5. Program LED CH1 & CH2

This green LED tells you that the 'program' input is active.

6. Bridged LED

This yellow LED tells you when the amplifier is in BRIDGE mode (= 480Watts)

Connect a sound source to the program or priority input 2 in bridge mode.



REAR panel

9. Earth lift switch

In case hum and buzz appears when a line source has been connected, lifting the audio ground can be a solution. Correct wiring can avoid this problem.

10. Mains socket

The unit can be connected to the mains circuit by a standard IEC type power cord. This socket contains a 8.0 AT, slow blow fuse. Use a screw driver to flip out the fuse compartment and to replace it by the same type. When this fuse blows frequently you should check the speaker load or bring the PA-2240BP to a qualified service centre. First check whether you didn't use a quick-blow fuse!

11. Priority control connector

a. At these terminals (-/+) 24V DC will be available (max. 0,6A) from the moment the 'priority switch' has been activated, to activate priority relays of local volume attenuators or other devices. In bridge mode only the channel 1 terminals can be used.

b. prior contact: when you shorten these contacts, the input of the priority line input will be activated. At the same time 24 V DC will be presented to terminals 11a.

c. prior input: here you can feed the audio source for paging, emergency messages, etc.. The signal should be at line level. Please use a balanced, shielded line cable. Connect the HOT signal to +, the COLD to - and the shield to G.

No microphones should be connected directly to this input without using a mic to line preamplifier.

12. Program input connector

Here you can feed the audio source for music playback (background music)

The signal should be at line level. Please use a balanced, shielded line cable. Connect the HOT signal to +, the COLD to - and the shield to G.

13. Speaker output connector. (2 channel operation mode)

For low impedance use COM and 4 Ω. Keep the impedance above 4 Ω.

For 35, 50, 70 or 100V speaker lines use COM and 35, 50, 70 or 100V terminals.

For 100V operation, the total minimum impedance of the loudspeaker line has to be 42Ω

70V = 21Ω / 50V = 10Ω / 35V = 5.1Ω .

Don't mix the types of speaker connections. Only one at the time should be used.

14. Emergency power supply.

You can power the amplifier directly from a emergency battery or power supply with 24V DC/6.5A (each channel). Remember that output power capacity will be reduced on emergency power supply.



15. Priority volume control

With this attenuator you can set the desired level of the line level signal inserted into the priority signal input (11c). This input becomes active when the prior contact is closed (11b)

16. Program volume

With this attenuator you can set the desired level of the line level signal inserted into the program signal input (12)

17. Bass control

Adjust as per your taste. In reverberant rooms intelligibility can be increased by decreasing the amount of bass. The centre position gives you a flat response. In 100V applications, it's not recommended to really boost bass because it can overload the amplifier or speakers too easily. We recommend to use this control only as low-cut or as well considered bass response adjustment.

18. Treble control

Adjust the level as per your taste or needs. Adding high frequencies gives brilliance to your sound. High freq. feedback can be removed by decreasing the amount of treble. The centre position gives you a flat response.

19. Airflow output

This airflow outputs should be kept free at all times !
To give the fan a longer life time, it only starts running when the heatsink reaches a certain temperature.

20. Bridge

To configure the amplifier to bridge mode (= 480Watts / 100Volts) use the following connections.

- 1) Connect the loudspeaker line, the + (hot) pole to the channel 1 amplifier 50V connector and the -(negative) pole to the channel 2 amplifier 50V connector.

Use the 35V connectors if you want to use the 70Volts setting or the 4Ω connections if you want to connect an 8Ω speaker.

- 2) Connect the audio signal to the channel 1 inputs. (in bridge mode the channel 2 inputs are not in use).


- 3) Push the bridge button, verify if the yellow led on the frontpanel is on.

Now your amplifier is capable of producing up to 480Watts into 100Volts speaker lines.

Push the bridge button to enable bridge mode.

Use the channel 1 audio inputs for bridge mode.

BRIDGE MODE	
OUTPUT	MIN. IMPEDANCE
100VOLTS	21 Ω
70VOLTS	10.5 Ω
4 Ω	8 Ω



Controls inside

Inside settings should only be done by persons familiar to electrical equipment!

A. Limiter active jumper

Your PA-2240BP has been shipped with the limiters enabled for both channels.

The jumpers are located on the inner PCB's on the rear side.

Channel 1 = jumper JP101 / Channel 2 = jumper JP201

Caution : removing the jumpers voids warranty.

B. Power supply fuses (inside the housing)

When one of these fuses blows, replace them by the same type.

Fuses marked F403 and F404 : 20A quick blow

Fuses marked F405 and F406 : 3.15A slow blow

The fuses are located inside on the power supply pcb.

When this happens frequently, contact your nearest dealer.

19" Rack mounting

The BP2240BP can be rackmounted. In this case, remove the 3 screws from the left and right side and mount the rack-ears with the supplied screws. Remember to provide adequate support at the rear of the amplifier, special mounting holes are provided at the rear.

Warning: never obstruct the free airflow around the amplifier's front, side and rear.

Maintenance

The amplifier is free of maintenance however regular cleaning of the air vents with compressed air is advisable to ensure long term reliability.

The cooling fan is a mechanical device and its function should be checked regularly.

If replacement becomes necessary, contact your local dealer.



Technical specifications

Type	2 x 240 watts power amplifier
Output power capacity	2 x 240 watts rms or 1 x 480 watts rms
Frequency response	35Hz - 22KHz (low cut inside at 50Hz)
Total harmonic distortion	<0.5% (1KHz nominal power capacity)
Signal to noise ratio	>95dB
Inputs	Program : 0dB - 10K / Balanced Euroblock Priority : 0dB - 10K / Balanced Euroblock Sensitivity : -1dB
Speaker outputs	channel 1 : 4 ohm, 35V, 50V, 70V, 100V / 240W channel 2 : 4 ohm, 35V, 50V, 70V, 100V / 240W Bridge : 8 ohm, 70V , 100V / 480W
Crosstalk	>75dB
Additional outputs	2 X 24V Priority output , MAX 0.6A
Tone control	Bass : 100Hz +10dB / -14dB Treble : 10KHz +10dB / -14dB
Controls rear panel	Priority volume control Program volume control treble control bass control priority control bridge - stereo earth lift switch
Power supply	230V AC (+/-5%) 50Hz 24V DC emergency supply
Power consumption	230V AC / 1050VA MAX 230V AC / 500 VA Program 24V DC / 13A Program
Fuse	8.0T (rear panel)
Dimensions	D X W X H in MM : 412 X 430 X 90 With 19" brackets monted : 483MM
Weight	Net weight: 21.70Kg / Shipping weight : 24.10Kg
Note	Above specs. are measured for lab purpose. As standard use, limiters are active and might influence the values above.