



2

Insert the wall anchors* to the wall and tap them flush with a hammer.
* Never use wall anchors on drywall.

4



5

